SERVICE BULLETIN: SPM6400



November 10, 2016

Product: DX6R 6-Channel DSMR[®] Radio System

- Issue: Closing the RaceWare[™] application or opening a 3rd party application and not re-opening the RaceWare application will turn off RF transmission (sleep mode) at the pre-determined time limit (default 5 mins) if no inputs are made on the touch screen.
- What To Do: Always keep the RaceWare application open and visible on the screen while driving to avoid losing RF transmission while driving.

THE RACEWARE APPLICATION WILL REMAIN ON AND WILL NOT STOP TRANSMITTING AS LONG AS THE RACEWARE APPLICATION IS ON AND VISIBLE ON THE SCREEN.

TIP: The Sleep Mode time can be manually set from 15 seconds to Never. Within the Android Operating System, go to, **Settings>Display>Sleep**. If you intend to drive while using other apps such as the calculator or Adobe Reader, it is recomended to reprogram Sleep Mode to Never.

Alternately, if WiFi is turned on in system settings, even if it is not connected to a network, the RF transmission will NOT turn off.

Horizon Hobby, LLC disclaims all liability and warranties for any consumer who does not act upon this bulletin. We apologize for this inconvenience. If you have any questions, please call Horizon Hobby Product Support at 877-504-0233.

Contact Information

Country of Purchase	Horizon Hobby	Contact Information	Address
United States of America	Product Support	productsupport@horizonhobby.com	4105 Fieldstone Rd Champaign, Illinois, 61822 USA
		877-504-0233	
	Sales	sales@horizonhobby.com	
		888-959-2304	

If you have questions and are located outside of North America or Europe, please contact the dealer where you purchased the product.

©2016 Horizon Hobby, LLC DSMR and RaceWare are trademarks or registered trademarks of Horizon Hobby, LLC. Android is a trademark of Google Inc. All other trademarks, service marks and logos are property of their respective owners. Patents pending.

Created: 11/2016